

Slim Double Brackets Assembly And Installation

Installing The Chain

- 1: a) Determine whether the control chain mechanism for the top blind will be on the left or right hand side.
- b) Select the Right or Left bracket for installing the chain diverter:
- If the chain mechanism for the top blind is to be on the left hand side, the chain diverter shall be placed on the Left bracket.



- 2: Position the chain diverter with the plastic pins facing the mounting holes and with the narrow part at the top, wide part at the bottom.



- 3: Insert the chain diverter pins into the mounting holes and press hard into place
- Tip: You may find it easier to insert one pin then apply a combination of horizontal and downward pressure on other pin. The diverter



- 4: Screw the diverter into place with the supplied screw,

Important Note Regarding Blind Roll



Top
(Reverse)

Bottom
(Standard)

Please note that the top blind must roll to the front (reverse roll) for clearance from the lower blind.

It is recommended that the lower blind roll to the rear (standard roll) by default for base rail separation.

Installing Idler



1: Determine where the idler pins are to be mounted



2: Insert the idler bearing into the centre of the brackets.

3: Rotate the idler bearing clockwise and lock into place.

Mounting The Blind Into The



1: Insert the idler end of the top blind into the corresponding idler bearing, depressing the idler pin against the bracket.

2: Insert the control chain mechanism end into the opposing bracket and lower so that the hook is engaged to prevent lateral movement.

3: Ensure that the rear side of the control chain from the top blind is running over the top of the chain diverter as shown.

4: Repeat steps 1 and 2 for the lower blind.

